

- Use in either vertical or horizontal orientation, to maintain a straight and level plane.
- Attach to the substrate (block, steel framing, wood frame construction - or other approved substrates) with approved fasteners, construction adhesive or tie wire to the lath as specified by the architect, ASTM C1063 and ASTM C926, local building code, and industry standard(s).
- In wood or metal framing, fasteners should penetrate framing members per code and be of approved size.

**To install**

- 1** Use “Aviators” or nippers to cut corner bead
- 2** Attach ends first, inserting nails or screws in a temporary position, through the larger round holes in the mounting flange. Set the bead.
- 3** Using a plumb line, position corner bead on substrate.

