

- Use in either vertical or horizontal orientation, to maintain a straight and level plane.
- Attach to the substrate (block, steel framing, wood frame construction - or other approved substrates) with approved fasteners, construction adhesive or tie wire to the lath as specified by the architect, ASTM C1063, ASTM C926 and D1784, local building code, and industry standard(s).
- In wood or metal framing, fasteners should penetrate framing members per code and be of approved size.

To install

- 1** Use “Aviators” or nippers to cut corner bead
- 2** Attach ends first, inserting nails or screws in a temporary position, through the larger round holes in the mounting flange. Set the bead.
- 3** Using a plumb line, position corner bead on substrate.

